

SENKO

For a perfect warm home!

instruction manual

PELLET STOVES SLIM MODERN

- **P 8 AIR**
7 kW
- **P 10 WATER + AIR**
12 kW



For a perfect
warm home!



Dear client, thank you for choosing a SENKO pellet stove !

This product was designed and manufactured to its minutest details in order to fulfil your every need for functionality and safety.

This Instruction manual will teach you to operate your stove properly, so please read the manual carefully before using the stove.

SENKO management

This pellet stove is designed according to the following Directives :

- **EU 305/ 2011** ⇒ *Construction Product Regulation*
- **EU 2015/ 1186** ⇒ *Regulation for the energy labelling of local space heaters*
- **2004/ 108 EEC** ⇒ *Electromagnetic Compatibility Directive*
- **2006/ 95 EEC** ⇒ *Low Voltage Directive*

And according to the following standards :

- **EN 14785** ⇒ *Room heaters fired by wood pellets*
- **EN 60335** } ⇒ *Safety of household and similar electrical appliances*
- **EN 62233** }
- **EN 61000** }
- **EN 55014** } ⇒ *Electromagnetic compatibility*

Symbols used in this *Instruction manual* :

• ATTENTION



• WARNING



• SAFETY



• ADVICE AND RECOMMENDATIONS



CONTENTS

| | |
|---|-----------|
| GENERAL | 4 |
| 1. WARNINGS AND SAFETY | 6 |
| 1.1. SAFETY DEVICES | 10 |
| 2. PELLETS | 11 |
| 3. TECHNICAL FEATURES | 12 |
| 4. INSTALLATION | 15 |
| 4.1. RECOMMENDATIONS | 15 |
| 4.2. PROPER INSTALLATIONS | 18 |
| 4.3. IMPROPER INSTALLATIONS | 18 |
| 4.4. CONNECTING TO OUTDOOR AIR | 18 |
| 4.5. CONNECTING TO CHIMNEY | 20 |
| 4.5.1. FLUE PIPES | 20 |
| 4.5.2. CHIMNEY | 25 |
| 4.5.3. CHIMNEY PREPARATION AND CONTROL | 26 |
| 4.5.4. CHIMNEY CAP | 27 |
| 4.5.5. CHIMNEY FUNCTION | 29 |
| 4.6. CENTRAL HEATING SYSTEM CONNECTION | 30 |
| 4.6.1. INSTALLATION TESTING | 33 |
| 4.6.2. RECEIVING AND MAINTAINING THE INSTALLATION | 34 |
| 4.7. DUCTED WARM AIR CONNECTION | 34 |
| 5. HANDLING THE STOVE | 37 |
| 5.1. PRE-IGNITION WARNINGS | 37 |
| 5.2. LOADING THE PELLETS | 39 |
| 5.3. CONTROL PANEL | 39 |
| 5.4. BEFORE FIRST SWITCHING ON | 42 |
| 5.4.1. DATE AND TIME MENU | 44 |
| 5.5. IGNITION / SHUT DOWN | 45 |
| 5.6. OPERATING MODE | 47 |
| 5.6.1. MANUAL MODE (<i>MANU</i>) | 47 |
| 5.6.2. AUTOMATIC MODE (<i>AUTO</i>) | 47 |
| 5.6.3. ECO MODE (<i>ECO</i>) | 49 |
| 5.6.4. WARM AIR FAN (<i>FAN</i>) | 50 |

| | |
|---|-----------|
| 5.7. ADVANCED FUNCTIONS | 51 |
| 5.7.1. AUTOMATIC SHUT DOWN (<i>SLEEP</i>) | 51 |
| 5.7.2. TIMER (<i>CHRONO</i>) | 52 |
| 5.7.2.1. WEEKLY PROFILES | 54 |
| 5.8. SETTINGS | 56 |
| 5.8.1. BACKLIGHTING | 57 |
| 5.8.2. COMBUSTION RECIPES (<i>PELLET AND AIRFLOW</i>) | 57 |
| 5.8.3. PELLET FEEDER FILLING (<i>CHARGE PELLET</i>) | 59 |
| 5.8.4. BURNER POT CLEANING (<i>CLEANING</i>) | 59 |
| 5.8.5. SWITCHING ON THE PUMP (<i>START PUMP</i>) | 60 |
| 5.9. TECHNICAL MENU | 60 |
| 5.10. USER INFO MENU | 60 |
| 5.11. ALARMS..... | 61 |
| 6. CLEANING AND MAINTENANCE | 64 |
| 6.1. BURNER POT | 64 |
| 6.2. HEAT EXCHANGER | 66 |
| 6.3. ASH PAN | 67 |
| 6.4. DOOR GLASS | 67 |
| 6.5. EXTERNAL SURFACE | 68 |
| 6.6. PELLET TANK | 68 |
| 6.7. FIREBOX DOOR GASKET | 68 |
| 6.8. CENTRAL FLUE GAS CHANNEL | 69 |
| 6.9. OUTPUT FLUE GAS CHANNEL | 71 |
| 6.10. INPUT PRIMARY AIR CHANNEL | 71 |
| 6.11. FIREBOX | 71 |
| 6.12. ELECTRONIC COMPONENTS | 73 |
| 7. MALFUNCTIONS / CAUSES / SOLUTIONS | 75 |
| 8. TECHNICAL SUPPORT | 77 |
| 9. TECHNICAL DATA | 78 |
| 10. TERMS OF WARRANTY | 79 |
| WARRANTY SHEET | 80 |
| INSTALLATION REPORT | 81 |
| NOTES | 82 |

GENERAL

- pellet stove P 8 AIR SLIM MODERN
- pellet stove for central heating P 10 WATER+AIR SLIM MODERN

are models from the SENKO pellet SLIM stoves palette which can best accommodate your space heating needs. Therefore, we ask you to **CAREFULLY READ THESE INSTRUCTIONS**, which will help you to achieve the best possible results already during the initial use. **The manufacturer is not responsible** for any consequences (people or animal injuries or property damages) resulting from **failure to comply with this Manual**.



The stove is hot during operation and the use of protective heat insulated gloves is compulsory during handling.



Children and infirm individuals are not allowed to handle the stove.

The external appearance of the stove is shown on the first page of this Manual. When ordering the stove or the spare parts, it is necessary to state its full designation, for example: E 2903, P 8 AIR SLIM MODERN, colour PC-3.

SIDE WALL COLOUR PALETTE:


- BORDEAUX → **PC-2**
- CREAM → **PC-3**
- ANTHRACITE GREY → **PC-7**
- GLASS (option) or GLASS DESIGN (option)

Pellet stoves are manufactured in accordance with the EN 14785:2006 norm and comply with all the requirements set by the norm.

The stove is packaged on a EURO pallet. During transport, the stove must be properly fastened in order to prevent tumbling or damages. The standard delivered stove set consists of:

- A) Pellet feeder motor;
- B) Flue gases suction ventilator;
- C) Warm air distribution ventilator (*below the firebox*);
- D) Motherboard;
- E) Flue gases temperature sensor;
- F) Pellet igniter;
- G) Airflow sensor;
- H) Primary air inlet pipe \varnothing 50 mm;
- I) Power supply cable;
- J) Burner pot;
- K) Ash pan - **ONLY ON SOME MODELS**;
- L) PVC regulation feet with screw;
- M) Instruction manual.

+ equipment for ducted warm air connection
(see **Figure 18**) - only at P-8 stove!



CAUTION! The stove weighs over 130 kg. Extra caution is necessary when unloading, transferring, moving and installing the stove in order to avoid physical injury.



1. WARNINGS AND SAFETY

SENKO pellet stoves are constructed in accordance with all the security measures prescribed by EN 14785 norm. Attention paid to every stove component assures safety from potential accidents for both the user and the fitter.

Our recommendations:

- a) **Prior to undertaking any operation on the stove the user is OBLIGATED TO READ AND COMPREHEND this *Manual*.**
- b) It is necessary to turn off the stove (the switch must be in position 0) and unplug the electric cable before any operation on the stove.
- c) During any operation on the stove, special attention must be paid to electric connections, especially bare conduit sections, which must not, in any way, leave the wire grips, thus avoiding direct contact with the conduit.
- d) **The stove must not be installed in rooms with gas stoves or cookers, in bathrooms, laundry objects or similar.** The same applies **for rooms and apartments which are vented via air facilities or hot air heating facilities with fans (air conditioning, kitchen hoods and similar), UNLESS** such facilities have safety devices which unfailingly prevent occurrence of underpressure of 4 Pa in the room where the furnace has been installed, i.e. rooms connected with external air.
- e) **The stove can be installed in a residential space and basement with normal air humidity and temperature from +5°C to +25°C (temperature of the surrounding area at the stove in operation).**
- f) **A pellet stove is not resistant to moisture and MUST NOT BE installed in moist rooms!**
- g) **In spaces where the temperature is less than 5°C (holiday house) it is necessary to ensure that the stove is working at**



minimum power or on the ECO mode (see *chapter 5.7.3.*). In central heating systems it is necessary to infuse the antifreeze into the system

- h) At room temperatures above 25°C, the safety systems on the stove can be activated.

i) **Due to stove operation and flame sound, it's not recommended to install the stove in bedrooms and relaxation rooms.**



- j) **For your own safety, DO NOT LEAVE THE STOVE TO OPERATE DURING THE NIGHT WITHOUT SUPERVISION!**



- k) The room, in which will be the pellet stove installed, must be large enough to prevent overheating of the stove → **the minimum volume of the room, in which will be the pellet stove installed, must be 4 m³ per kW of stove nominal power!**



- l) In the room in which the stove is located you should always have installed additional heating devices (eg. radiators, underfloor heating, etc ...). This is especially important in the transitional period (autumn / spring), when the stove is not in use, but you use heat from other energy sources (solar, biomass, etc.) in combination with a water storage tank (buffer). Then such heating is sufficient, but you need a heating device which will warm up the space.

- m) **It is necessary to adhere to all European, national and local regulations (norms) applicable in the country of product installation.**



- n) **The manufacturer is not responsible for any consequences (people or animal injuries or property damages) resulting from failure to comply with this Manual.**



- o) This Manual is an important part of the product, and is therefore necessary to ensure it is kept next to the product, especially in cases the product is handed over to a different owner or relocated.

- p) This stove is intended for space heating and may not be used for different purposes. Upon removing the protective foil from the stove, inspect it for damages and missing parts. Should anything be missing contact the vendor you purchased the stove from.
- q) Prior to commencing the firing procedure, the stove **MUST be connected to the chimney (and central heating) installation!**
- r) **Connecting the stove to the central heating system must only be carried out by authorized service personnel. Servicer that connects the stove to the central heating system must guarantee the correctness of the system.**
- s) **Never use any flammable liquids for ignition of pellets!**
- t) **Do not leave the pellet bag in contact with a hot stove!**
- u) All stove parts enable good and proper functioning of the stove and, when necessary, must be replaced by original spare parts made exclusively by the manufacturer (failure to install original parts results in void warranty!)
- v) In order to maintain product functionality and to protect it, **regular stove maintenance (service)** must be executed in accordance with the Manual (at user's expense) depending on the pellets used - **after 1500 or 2000 operating hours** OR once a year (usually before the heating season) - for A1 quality pellets. For A2 quality pellets and those without a certificate, the complete stove service should be done before. **The consequences of alarms A01, A02, A03, A04 and A07 are not warranted.** **THE STOVE USER IS OBLIGED TO REGULARLY CLEAN THE STOVE, ESPECIALLY ACCORDING TO CHAPTERS 6.8-6.11.**



It is also necessary to mention:

- **All stoves before shipment may be activated and tested.**
- Children and infirm individuals are not allowed to handle the stove.





- It is **FORBIDDEN** to dry a laundry in front of the grille!
- Do not touch the stove with wet or moist body parts and ensure that the product is always plugged to a properly grounded socket.



- **The stove is hot during operation and the use of protective heat insulated gloves is compulsory during handling (opening and closing of firebox door, removing the ash pan and similar).**

- It is forbidden to alter safety rules without the permission or instructions by the manufacturer.
- Do not pull out, remove or bend electric cables from the stove even if the stove has been disconnected from the power grid.
- Avoid plugging or reducing the dimensions of air supply opening in the room where stove has been installed. Air supply openings are necessary for proper combustion. Minimum combustion air opening is 10 cm x 10 cm (or a hole with approximate diameter of 12 cm).



- **During regular stove operation, firebox door must be closed at all times.**
- Control possible primary air supply and flue gases channels for possible clogging before activating the stove after a long period of inactivity of the stove.



- Following repeated attempts to turn on the stove, accumulated non-combusted pellets must be removed from the firebox prior to subsequent attempt.

- **Pellet tank lid must be closed at all times.**



- **In case of chimney fire, turn off the stove, unplug the power supply cable, close primary air inlet and don't open the firebox door. Extinguish the fire using appropriate fire extinguishers. **NEVER EXTINGUISH A FIRE WITH WATER!** In case of fire also call the local fire department. Comply with local regulations for fire protection!**



- If you lose this Manual, you can get a copy from SENKO Company or its authorized representative. You can also find it at <http://en.senko.hr/>

1.1. SAFETY DEVICES



SENKO pellet stove consists of the following safety devices:

- **Motherboard** ⇒ intervenes directly and activates the alarm until the stove completely cools off in operating conditions which deviate from the pre-set safety conditions ;
- **Fuse** ⇒ protects the stove from sudden changes in electricity voltage (max.6,3 A and 250 V) - see *Figure 47* ;
- **Pellet tank temperature safety probe** ⇒ in the case of too high pellet tank temperature (max.110°C), the probe automatically blocks pellet feeding and activates the alarm **A03** ;
- **Water tank temperature safety probe** ⇒ in the case of too high boiler water temperature (max.95°C), the probe automatically blocks pellet feeding and activates the alarm **A18** ;
- **Flue gases temperature measurement probe** ⇒ in case of excessive flue gases temperature (max.220°C) the probe automatically resets the stove to normal temperature values (minimum power – level 1, i.e. *fire 1* on the control panel) OR activates the alarm **A04** ;
- **Room temperature measurement probe** ⇒ in case of higher room temperature from the set point the probe automatically resets the stove to normal temperature values (minimum power – level 1, i.e. *fire 1* on the control panel) - see *Figure 28* ;
- **Water temperature measurement probe** ⇒ in case that the water temperature increases above 85°C, the probe automatically resets the stove to normal temperature values (minimum power – level 1, i.e. *fire 1* on the control panel) ;
- **Primary combustion air flow measurement probe** ⇒ in case of insufficient (or excessive) chimney diameter, this probe automatically regulates (to a certain level) the speed of flue gases ventilator, i.e. primary air flow, in order to achieve optimum fuel combustion in the firebox.

2. PELLETS

Pellets are pressed wooden waste (sawdust and similar) obtained by mechanic pressing in special machines. Apart from being an **ecological fuel**, pellets also have a technical advantage over other wooden biomass – **they have the highest calorific value and very low humidity** (10% max).



The pellets you use **must be certified** in accordance with **EN 14961-2, Ö-Norm M 7135, DIN 51731** or **ENplus-A1** norm.



How to determine pellet quality?

- They must be cylindrical with a constant diameter and must have a shiny surface!
- Their diameter must be **5 - 6 mm** and their length **10 - 40 mm!**
- There must not be too much sawdust or dust in the packaging!
- The packaging must be hermetically sealed (due to potential exposure to moisture)!
- The pellets must break, but not crack!
- Put a handful of pellets into a water container. If the pellets are good quality, they will sink to the bottom, otherwise they will float!



- **Pellets must be stored in dry conditions!**
- **Use of low quality pellets or any other fuel adversely affects the functionality of your stove and can result in void warranty and annulment of manufacturer responsibility!**



3. TECHNICAL FEATURES

SENKO pellet SLIM MODERN stove is constructed for the purpose of heating residential buildings, but also to serve as a piece of decorative element in every room. Stove centre and load bearing construction are made from steel sheets. Fan blows warm air from the stove to the room through grids on the front side of the stove AND/OR through the channel for ducted warm air. The second fan is leading the primary air to the firebox and at the same time flue gases are lead from the firebox to the chimney.

At AIR stoves - internal part of the firebox is made of vermiculite – self-cleaning, resistant material ensuring high heat capacity. At WATER+AIR stoves - internal part of the firebox (boiler) is made of highly resistant quality boiler sheet according to EN 14785. Firebox is equipped with door with fire resistant glass. This solution provides an aesthetically pleasing visual effect of flame in the firebox, simultaneously preventing the egress of ash and smoke into the heated area.

THE KEY:

- ① Port for WI-FI module connection
- ② Port for connection to PC / room thermostat (see *Figure 28*)
- ③ Room temperature measurement probe (see “P” on *Figure 28*)
- ④ Main switch 0/1
- Ⓐ Ø 50 mm – primary air inlet
- Ⓑ Ø 80 mm – flue gases outlet
- Ⓒ Ø 80 mm – connection point for ducted warm air (see *Figure 18*)
- Ⓓ Touch screen panel
- Ⓔ Cleaning hatch lid
- Ⓕ Pellet tank lid (see *Figure 21*)
- Ⓖ **cold** water
- Ⓗ **warm** water
- Ⓛ R3/4" F – safety valve (2,5 bar)
- Ⓜ R1/2" F – valve for boiler filling / emptying
- Ⓟ Circulation pump



P.10 WATER+AIR SLIM MODERN




Figure 1b

4. INSTALLATION

4.1. RECOMMENDATIONS




Figure 2

We advise you **to check** the following elements **prior to installation**:

- Appropriate minimum volume of space where the stove will be installed (avoid placing the stove into hollow or narrow spaces under 40 m³ of volume);
- Ensure suitable and proper exchange of primary air necessary for combustion via connection with external air;
- Proper execution of chimney and smoke venting pipes.



Prior to installation it is necessary to **control** proper **positioning** of the stove and the chimney, which must comply with:


- Prohibitions concerning the installation;
- Safety distances;
- Limitation prescribed by the local administrative regulations or special safety measures prescribed by the authority;
- **It is not allowed to install the stove in rooms where another heating device without the autonomous air exchange already exists.**
- **It is forbidden to install the stove in the room with explosive atmosphere.**



| | |
|----------|--|
| A | 500 mm from the back wall |
| B | 500 mm from the side wall |
| C | 800 mm from the front grid |
| D | 500 mm floor protection |
| E | 300 mm (measured from the maximum angle of firebox door opening) |

Table 2

Figure 3






Adjoining walls must be constructed of brick or concrete, or other non-flammable materials, i.e. protected with insulation. The stove emits heat, especially on the firebox level, therefore, **no flammable or heat sensitive objects must be placed nearby** (for example, alcohol, paper, plastic objects...).



The stove must be installed with adherence to minimum prescribed measures and constant control of the **safety distance from the walls and the furniture** (figure 3). If the floor is made of flammable material (e.g. wooden parquet) it must be protected with a single plate made of non-flammable material which must be placed under and around the stove to prevent floor overheating problems (figures 2 and 3 – floor protection).

| | Flammable objects | Non-flammable objects |
|----------|-------------------|-----------------------|
| A | 200 mm | 100 mm |
| B | 1500 mm | 800 mm |
| C | 300 mm | 200 mm |

Table 3



We recommend to install the stove as close to the smoke venting pipe as possible, limiting the number of roundings to a minimum (max 3 + inspection and cleaning T-piece) and chimney horizontal parts (**max total 3 m with a 3-5° incline**) ⇒ see 4.5. *Connection to chimney.*

4.2. PROPER INSTALLATIONS

Only devices that function as a closed system (close chamber) or don't create underpressure with regard to the external ambient may be installed or already exist in the room where the stove is to be installed.



Installation of food processing devices and kitchen hoods without suction is allowed only in rooms used as kitchens.

4.3. IMPROPER INSTALLATIONS

Devices that **must not** exist nor may be installed in the rooms where the stove will be installed are:

- kitchen hoods, air-conditioning devices;
- collective type ventilation pipes.



When the afore mentioned devices are located in the adjoining rooms, which are in contact with the room where SENKO pellet stove is installed, it is forbidden to use these devices simultaneously in cases where there is a risk that underpressure will occur in one of the two rooms with regards to the other.



4.4. CONNECTING TO OUTDOOR AIR

For proper stove function and good distribution of heat it is necessary to position the stove in a place where there is an opening for intake of external (primary) air necessary for pellet combustion or where one can be constructed. **Minimum opening surface must be 100 cm²** (figures 5a, 6). The opening must be constructed to prevent any form of clogging (**protected by grid, metal mesh or appropriate protection**).






Air may also be supplied from adjoining rooms (figure 5b). It is important that these rooms are in constant free supply of external air. Adjoining room must meet all the criteria listed above with regard to the installation room and must not be used as a bedroom, bathroom or any space where fire may occur (e.g. garage, woodshed, flammable material storage room and similar).



If the air necessary for combustion is sucked via pipes directly from the external environment, a round pipe in a 90° downward incline must be installed outside, equipped with a protective grid, due to birds and potential accidental clogging.

Air can be supplied from external environment through external air connection ($\varnothing 50$ on the stove backside) via pipe, up to 3 m long maximum (it must be taken into account that each 90° elbow matches 1 linear meter).




4.5. CONNECTING TO CHIMNEY

4.5.1. FLUE PIPES

When installing chimney, elements made from non-flammable materials, which are suitable and resistant to combustion products and their potential condensation, must be used. **It is forbidden to use flexible pipes which are not made from acid-resistant material** when connecting the stove with the chimney, even if the channels already exist.



Figure 8



1 – Installation of $\text{Ø}100\text{mm}$ diameter chimney with space around the pipe (B):

- **min 100 mm**, if the pipe is near non-flammable materials, such as concrete, brick, and similar
- **min 300 mm**, if the pipe is near flammable materials, such as wood and similar

In both cases, appropriate insulation between the chimney and the ceiling is necessary

2 – Existing chimney; minimum smoke venting pipe diameter $\text{Ø} 80\text{mm}$ with external chimney inspection and cleaning hatch

3 – External chimney made of insulated stainless steel pipes, $\text{Ø}80\text{mm}$ minimum diameter. The entire construction must be safely installed onto the wall and must have a protective cap on top (see *chapter 4.5.4.*)

4 – Smoke venting system with T-pieces enabling easier access when cleaning the chimney without the necessity of deconstructing the pipes.

A – see *figure 14* and *chapter 4.5.4.*

B – space around the chimney pipe

C – minimum 500 mm

D – maximum 3 m

E – minimum 50 mm

F – minimum 3°

G – insulation

H – reduction from $\text{Ø}80$ to $\text{Ø}100$ mm
J – maintenance and cleaning opening

K – maintenance and cleaning hatch

L – T-piece with maintenance and cleaning opening

M – fresh external air supply grid

Smoke venting pipes must not be conducted through rooms where installation of combustion devices is prohibited. Pipe installation must be executed in a manner **ensuring smoke impermeability** during stove operation, **limiting condensation** and disabling transfer of condensate back to the device.





Figure 9



IT IS NOT RECOMMENDED TO USE THE 90° ELBOW AS THE FIRST ELEMENT OF THE INSTALLATION SINCE THE ASH MIGHT QUICKLY CLOG THE SMOKE VENTING SPACE AND CAUSE PROBLEMS IN STOVE AND CHIMNEY FUNCTIONING!

Installation of horizontal parts should be avoided as much as possible. When parts in question are those which must reach let-offs on the ceiling or walls unsymmetrical with the stove smoke let-off, the connection is to be executed via pipes with inclines not exceeding 45° (*figure 10*).



When installing the flue pipes, please follow the instructions below:

- horizontal parts must have a minimum 3° upward incline,
- the length of horizontal part must be kept at minimum, and should not exceed 3 m.
- number of elbows (90° angles) should not exceed 4 (including the T-piece) – should you need more than 4 elbows, use a pipe with internal diameter of \varnothing 120 mm),
- chimney diameters exceeding 120 mm are not suitable for direct connection to the stove, and a suitable, min. 80 mm diameter flexible smoke venting pipe (made from acid-resistant stainless material), is to be conducted through such a chimney and the chimney is to be insulated to prevent cold air from penetrating into the flue pipe!



⇒ connecting the stove to a chimney of wider diameter will result in increased thermal loss of the stove, with subsequent increase in the fuel consumption !

The stove is connected to the chimney with flue pipes with **minimum diameter** of \varnothing **80 mm** (pipe length up to 3 m), OR \varnothing **100 mm** (with pipe length exceeding 3 m). The length is obtained by adding the parts of the horizontal and vertical pipes, keeping in mind that each 90° elbow corresponds to 1 linear metre.



CAUTION! DO NOT CONNECT the flue pipe to a common flue pipe used for other heat generators (water heaters, fireplaces, cookers and similar) → see *figure 11*.



Figure 10





Figure 11



IMPORTANT:



- ⇒ use of elements with a different incline is prohibited !
- ⇒ smoke venting pipe must enable collection of soot and brushing !
- ⇒ smoke venting pipe must be of constant diameter !
- ⇒ potential change of the diameter is allowed only on the connection point with the chimney !
- ⇒ it is prohibited to conducted other channels or pipes through the smoke venting pipe !
- ⇒ it is not allowed to install devices for manual regulation of suction onto devices for forceful suction !


4.5.2. CHIMNEY

The chimney must meet the following requirements:



- Be **impermeable** to combustion products, **waterproof** and appropriately **insulated**;
- Be **constructed of materials that are able to withstand regular mechanical friction, heat and effects of combustion products and potential condensation**;
- Be **connected vertically** and with a decline from the axis up to 45°;
- Be appropriately **physically removed from flammable materials** by air-filled spaces or appropriately insulated;

Figure 12



- Must have **circular internal cross-section** (cross-section can also be square or rectangular with rounded angles and a radius no less than 20 mm) → see *figure 12* ;
- Must have a **constant internal cross-section** which is free and independent;
- It can have a rectangular cross-section with a maximum ratio between the sides of 1,5 → see *figure 12*.

We advise to **equip the chimney with a chamber for collection of solid materials and potential condensation products** and to install it below the entry point into the smoke venting channel, thus allowing for easy opening and inspection via impermeable hatch.



IMPORTANT

- **BEFORE connecting to the chimney it is necessary always to make a calculation (according to EN 13384 and all other standards for the chimney dimensioning)!**
- **The chimney has a very important function of the smoke exhaust in the event of a power failure and therefore MUST BE well and properly dimensioned!**



4.5.3. CHIMNEY PREPARATION AND CONTROL

Prior to stove installation, it is necessary to inspect the chimney – diameter, height, potential clogging and damages. The chimney must be **certified by an authorized local chimney-sweeper.**




The effective **chimney height** must be **at least 5 meters** from the point of connection of chimney and the stove (*figure 13b*).

The chimney must be **at least 0,5 meters remote above the roof ridge** (see *figure 14*).

The chimney must be smooth on the inside, well insulated and well fastened. All cleaning hatches must be well fastened. All gaskets must be regularly inspected and replaced when necessary.

Figure 13



When connecting the stove to the chimney it is necessary to adhere to local, national and European regulations (norms) – DIN 4705.

It is necessary to ensure that the connection between the stove and the chimney is executed tightly and impermeably. **Smoke venting pipe must not penetrate into the chimney clear opening shaft** (figure 13c).

Differences between the proper and improper connection of stove to the chimney are displayed in figure 13.

4.5.4. CHIMNEY CAP

Chimney cap must meet the following requirements:

- **identical internal cross-section** to that of the chimney,
- **operational exit cross-section no less than the double inner cross-section of the chimney,**

- constructed **to prevent rain, snow, leaves and other foreign bodies from entering** the chimney,
- constructed **to enable expulsion of combustion products in case of wind** from any direction and incline,
- installed **to enable proper dispersion and dilution of combustion products outside the reflux zone** (backflow) because the counter pressure occurs here. Therefore, it is necessary to adhere to limitations listed in *figure 14*,
- **mechanical appliances for flue gases suction are not allowed.**



FLAT ROOF

PITCHED ROOF





Figure 14

Z=REFLUX ZONE

Table 4

| Roof slope | Distance between the roof ridge and the chimney | Minimum chimney height (measured from the roof surface) |
|------------|---|---|
| β | A, m | H_{min}, m |
| 15° | < 1,85 | 0,5 m above the roof ridge |
| | > 1,85 | 1 m from the roof |
| 30° | < 1,5 | 0,5 m above the roof ridge |
| | > 1,5 | 1,3 m from the roof |
| 45° | < 1,3 | 0,5 m above the roof ridge |
| | > 1,3 | 2 m from the roof |
| 60° | < 1,2 | 0,5 m above the roof ridge |
| | > 1,2 | 2,6 m from the roof |

4.5.5. CHIMNEY FUNCTION

Among all the meteorological and geographical factors that influence the chimney function (rain, fog, snow, insolation period, etc.) **the wind is most certainly the crucial one**. Apart from the pressure caused by the temperature difference between the flue gases and the outer chimney air, there is another type of pressure – **wind dynamic pressure**.



Ascending wind ALWAYS has the effect of increasing the pressure, i.e., **underpressure (flue draught)**, provided the chimney is properly installed. **Descending wind ALWAYS has the effect of decreasing the draught** ⇒ overpressure occurs. Apart from wind direction and velocity, chimney position in relation to the house roof and surrounding area is also important (*figure 15*).





Figure 15

The wind also influences the chimney function indirectly by creating areas of high (overpressure) and low (underpressure) pressure, both inside and outside the residential area (*figure 16*).

Pressure that facilitates chimney function can occur in rooms directly exposed to the wind (B), but it can also adversely affect the chimney through external pressure if the chimney is situated on the side exposed to wind (A). Contrary to that, underpressure can occur in lee rooms (C), adversely affecting functions of the chimney situated on the opposite side (D) from the wind direction.



4.6. CENTRAL HEATING SYSTEM CONNECTION

only at P-10 stove!

Prior to commencing the firing procedure, the stove must be connected to the central heating system and the **boiler must be filled with water**.



① CONNECTIONS TO THE SYSTEM

The pipe installation **must be executed in accordance with valid technical regulations** and DIN 4751 norm – part 1 for open systems and DIN 4751 – part 2 for closed systems, following **professional standards**, and **only by an authorized expert**.



It is not allowed to reduce the pipe diameter connecting the boiler to the heating installation connection point. Otherwise, the warranty will be void.

Prior to connecting the boiler to the heating installation, **the pipelines are to be thoroughly cleansed from potential filth sediments**. This prevents boiler overheating, system noise, pump malfunctions and mixing valve malfunctions.





IT IS STRONGLY RECOMMENDED TO WASH THE ENTIRE SYSTEM BEFORE CONNECTING IT IN ORDER TO GET RID OF POSSIBLE RESIDUES AND DEPOSITS.



The connection to the heating system is executed via union flat joint, with OR without the mixing valve onto a closed or open system.

Connect the stove USING FLEXIBLE PIPES so that the stove is not too strictly connected to the system, and to allow slight movements.



THE STOVE IS FACTORY SET TO CONNECT TO THE CLOSED CENTRAL HEATING SYSTEM !



Regardless of the expansion tank (located beneath the left side panel) built-in pellet stove, central heating system must also have its own expansion tank, adjusted to the expansion tank in the stove.



The stove is equipped as standard with a **safety valve 2,5 bar** (located beneath the left side panel). **An outlet of the safety valve MUST be carried out into the sewer.** The water drain pipe must be adequate to support the water's high temperature and pressure.



It is necessary to **install the vent valve** (regardless of the valve built-in stove) **at the highest point of the installation**. When filling the boiler and the radiator system it is necessary to open the mixing valve, if one had been installed; **adequately deaerate the boiler and the heating system.**



In places of any connection points on the stove (water, chimney, air inlet...), **inspection hatches must be installed for system maintenance and servicing purposes.** Also, **YOU SHOULD ADHERE TO THE SAFETY DISTANCES** (see *Figure 3*).

ORIENTEERING and SIMPLIFIED scheme of connecting to a central heating system




Figure 17

② **SYSTEM FILLING**



The boiler is filled with water via valve R1/2" located beneath the left side panel. **Continuous circulation of water through the boiler** must be ensured. The boiler **must be well deaerated** prior to operations commencement. During filling, any air in the system is released from the **automatic vent valve** located at the highest point of the boiler, beneath the left side panel.



The **filling pressure** of the boiler **WHEN COLD** must be **1 bar**.

For proper operation of the stove **WHEN HOT**, the pressure in the boiler must be **1,5 bar**.



To monitor the system pressure (and temperature), the central heating system must be fitted with thermo-manometer.

4.6.1. INSTALLATION TESTING

Prior to initial firing:

1. It is necessary to **check if the boiler and the entire heating system are filled with water and well deaerated**. Also check if the smoke uptake pipe is properly fastened,
2. **Activate the safety valve and check its proper functionality,**
3. **Check the pump operation** (you can do this only if the stove is in OFF).



It is necessary to turn on the pump using the following steps on the touch screen panel: *Main Menu* → *Settings* → *Start Pump* → 0/1 → 1.



If the pump doesn't work, the rotor is blocked. Switch off the power, remove the right side wall, remove the pump head (unscrewing 4 screws), clean the rotor, spin the shaft with a screwdriver, check the electrical connections of the pump and deaerate the entire system. Check again the pump operation.

After initiation make sure:

- there is no leakage of any kind,
- that the entire installation is deaerated,
- that the water temperature in the boiler is increasing,
- that boiler operations do not result in condensation in the chimney.



Repeat the entire inspection after several days of constant firing !

4.6.2. RECEIVING AND MAINTAINING THE INSTALLATION

When receiving the installation, inspect the installation in its entirety with the contractor. **The contractor is obligated to provide basic information about the installation operations and indicate the position and function of the installation key components.** Also, the contractor is obligated to complete the Installation report which can be found at the end of this *Manual*.



NOTE: Before installation commissioning please read, together with the contractor, the installation and operating instructions of the pump! The pump is located behind the right side panel (see “P” on *Figure 1b*) !



Deaerate the entire heating system after several days and refill it with water if necessary.

Inspection of installation working performance is to be executed at least once a year by an authorized maintenance technician. This will ensure safe working performance of the boiler, as well as economic and immaculate heating.



In case of installation faulty operation, contact your central heating installation contractor exclusively !



4.7. DUCTED WARM AIR CONNECTION

only at P-8 stove!

The stove is equipped with a ducted warm air connection on the top -




Figure 18

see "C" on *Figure 1a*. If you want to use the warm air duct, first you must connect the parts received with the stove - see *Figure 18 and 19*.

- 1 = pipe extension
- 2 = air deflector
- 3 = screws

The procedure for connecting is described in following Figure.

Figure 19


1. Open the pellet tank lid and remove the top decorative sheet metal





2. Remove the front grille by unscrewing the 4 screws



3. Unscrew the 3 screws and mount the air deflector ("2" in Figure 18) using this same screws



4. Remove the black plate and if necessary, take out the round cover by pressing onto the weakest juncture (on black plate and also on the sheet metal beneath). Connect the pipe extension ("1" in Figure 18) to the sheet metal using the screws ("3" in Figure 18)



5. After the pipe extension is attached, put the black plate back to its place



6. On the end, put the top decorative sheet metal to its place and connect the duct



IMPORTANT: You can use the $\varnothing 80$ mm pipe with maximum length of 2 m + 1 pc of 90° elbow.





NOTE: through the duct it can pass about 15% of the warm air, the rest of the heat goes through the front grille!

ORIENTEERING and SIMPLIFIED scheme of ducted warm air connection




Figure 20

5. HANDLING THE STOVE

5.1. PRE-IGNITION WARNINGS

During the first several times the stove is activated, we advise you to adhere to following recommendations:



- There is a possibility that the stove will emit a light odour which is the consequence of used protective coatings. This smell disappears after a few hours of stove operation;
- Ventilate the room several times;
- This stove should **NEVER** be used for waste incineration.

During the heating and cooling periods **the stove material is exposed to expansion and contraction which may result in light cracking sounds.** This occurrence is perfectly normal since the stove is constructed of steel sheets and should therefore not be considered a malfunction.



- **Do not use any flammable liquids to ignite the pellets!**



Prior to activating the stove, check the following:

- **pellet tank must be loaded with pellets,**
- **the firebox must be clean,**
- **burner pot must be clean and empty,**
- make sure you **properly install it back into the casing** – *Figure 37a,*
- make sure that the firebox **door** are hermetically **closed,**
- make sure that the **power cable is properly connected,**
- backside **switch** must be set to **1.**



It is of the utmost importance **not to increase the heating power to maximum already in the beginning;** increase the power gradually instead. In manual mode use lower heating levels (e.g. *fire* 1-2-3). After several minutes you can use the remaining available heating levels (*fire* 4-5), BUT keep in mind that the **stove may operate on maximum (nominal) power up to 3 h.** In this manner, damages that may occur on construction materials are avoided.



After longer periods of inactivity, all pellet residues must be vacuumed from the tank due to the fact that they can absorb water which alters their original properties, making them unsuitable for combustion and transport to the firebox.



It is MANDATORY that before first ignition you make the calibration or pellet feeder correction according to *Chapter 5.8.2.* and *Table 10.*



In case of power failure, and when power returns, the flue gas fan will work with its maximum speed to extract the remaining smoke from the firebox. The display will show "SHUT DOWN". After this process is complete and the stove reaches the state OFF, you must manually turn on the stove by pressing the ON/OFF key (for the duration of 2 sec).



5.2. LOADING THE PELLETS

Lift the pellet tank lid. Pour pellets into the tank. Maximum tank capacity depends on the stove type.



- Do not try to remove the protective grid from the tank!
- While loading the pellets, the scoop (or bag) must not come into contact with the hot stove!
- Do not pour any other fuel other than pellets compliant with norms mentioned in *Chapter 2* into the tank!



Figure 21

5.3. CONTROL PANEL

This control panel has a graphic **easy-to-use touchscreen**. It consists of **17 languages inside**: ENG-ITA-POL-ROU-HRV-SLO-SRB-BUL-RUS-TUR-GRE-HUN-NED-POR-DEU-ESP-FRA.





Figure 22a



KEY: 1 – ON/OFF (turning on / turning off)

2 – Actual stove state

3 – Date and time

4 – Chrono (timer)

5 – Warning sign

6a – Power level/Fire selection and changing

6b – Room temperature selection and changing

7 – Warm air fan speed level

8a – Manual operating mode

8b – Automatic operating mode

9 – Water temperature selection and changing

10 – Settings menu

11 – User Info menu

12 – Actual room (or water) temperature

13 – Eco mode active

NOTE: All explanations hereinafter will refer to the buttons on this *Figure 22*



This is the main (START) screen. From here you can choose:



- to set the Chrono function, by clicking the clock icon at the left upper corner (4);
- to turn on or shutdown the stove, by clicking the icon at the upper-right corner (1);
- to set the power, by clicking the fire icon at the lower-corner (6a);
- to set the ventilation level, by clicking the fan icon, next to the previous flame icon (7);
- to choose the way you want manage your comfort, choosing manual or automatic modality (8);
- to set the water temperature, by clicking the blue icon (9) at the last of the left four icon group;
- to access in the Settings sub-menu, by clicking the gear icon (10);
- to access in the User Info screen, by clicking the “I” letter icon, at the right side (11).

Useful information for understanding the functioning of the control panel:



- Backlight of the control panel screen turns off after approximately 60 seconds unless any key is pressed. To turn on the backlight again, press anywhere on the control panel.
- The display always shows the stove operating status (ON, OFF, IGNITION, SHUT DOWN...) which indicates the currently activated settings (CHRONO, SLEEP, AUTO, ECO...).



- **When changing the heating power it is important to note that the ascending power changes with a delay of 1 minute, while the descending power changes with a delay of 2 minutes.**
- Should you, during alteration of a parameter in any menu, fail to confirm the change by pressing the checkmark button, and leave the key inactive for 60 seconds, the change is NOT saved.


You can activate also a **Standby Screen** (see *Figure 23*) - a kind of a screensaver, by **sliding with finger from the left to the right** in the main screen. To return to the START screen, slide your finger from right to left.



Figure 23

5.4. BEFORE FIRST SWITCHING ON

Plug one end of the power supply cable into the socket (**the socket must be grounded!**) and connect the other end to the switch on the backside of the stove. After connecting the power supply cable onto the backside of the stove, **set the switch to position (I)**. As soon as the switch turns on the power supply, the control panel should produce an audio signal.





Once the control panel has been turned on, SENKO logo appears on the screen, while under the logo there is a stove model name. After approximately 12 seconds, „**START**“ screen appears (*Figure 24*) ⇒ this indicates that the system is ready.





Figure 24

As shown in the *Figure 24*, in the bottom line you can choose:




1. **Room temperature** (5-40°C) - if you previously select AUTO operating mode; 
2. **Heating power** - Fire (1-5) - if you previously select MANU operating mode; 
3. **Warm air fan speed** (1-5 or A); A = *automatic*
4. **Automatic or Manual** operating mode;
5. **Water temperature** (30-85°C) - if your stove is for central heating;
6. **Main menu** - enables the choice of additional functions (see *chapter 5.8.*);
7. **User info menu** - includes the list of values and functions related to the stove operations control.



Any change you have made must be confirmed by pressing , otherwise the change will not be saved. By pressing  you can return to the previous menu but without saving the changes.

5.4.1. DATE AND TIME MENU

Figure 25a



Clicking the date (1) you can set the current date. The weekday is automatic setted by the system.

Figure 25b



Similarly, if you click on time (2), you can set the current time.

5.5. IGNITION / SHUT DOWN

The stove is **turned ON** by pressing the **ON/OFF** key on the control panel for the duration of 2 seconds (key 1 – Figure 22a). The control panel will produce an audio signal and the screen will display the **IGNITION** option.





Figure 26



After initial ignition which may last up to 20 minutes maximum (# - see next page) (every subsequent ignition lasts 5 - 10 minutes), the stove gradually achieves normal operation status.



The first attempt to activate the stove may not be successful since the pellet feeder (spiral) is completely empty at the beginning and does not distribute the same quantity of pellets into the firebox every time. In that case, the control panel produces an audio signal and **alarm A01** appears on the screen (see Table 13 and Figure 36)! 



Cancel the alarm on the control panel (hold the green button for longer than 2 seconds), wait until the stove has cooled to the state OFF, clean the burner pot and repeat stove ignition sequence !



If, after reactivation (around 20 minutes), the pellets are not yet ignited, check whether the burner pot is properly set. The burner pot must completely adhere to its casing and must not contain any ash.

If the alarm A01 recurs, see **Informations** in **Table 13**.

Should ignition malfunctions appear even after this check, there is a problem in certain stove components OR the stove is not properly installed
→ clean the firebox and contact the authorized maintenance technician!




you can avoid problems with initial ignition by activating pellet dosage function prior to the activation of the stove



this function can be found in **Settings** menu under **Charge Pellet**

you can activate this option by clicking on it OR set the button on "I"

after activating pellet dosage, it is necessary to wait for several minutes until the pellet feeder spiral is filled and first pellets are distributed into the burner pot



after that turn off the dosage by setting the button on "0" and return to START screen

The stove is turned OFF by pressing the ON/OFF key on the control panel for the duration of 2 seconds (key 1 – Figure 22a). After pressing this key, the cooling stage is initiated. At this stage, pellet distribution to the firebox is stopped and cleaning of the firebox (ash is blown out → fan operates at maximum speed) and continual stove cooling are initiated. The cooling stage **may last 20 to 60 minutes**[Ⓞ], depending on how long the stove has been operating on maximum power and its location. After the cooling stage, **OFF** appears on the display (stove turned off).

[Ⓞ]**If you want to reduce the shutdown duration of the stove** which was working on power 1 (Fire: 1) until shutdown, before switching off the stove you must set the heating power to 5 (OR warm air fan set to *Fan: 5*), and for approximately 5 minutes switch off the stove.






Figure 27



- **Never unplug the power supply cable from the socket to turn off the stove!**
- **Never set the switch to position “0” to turn off the stove!**
- Please wait while automatically shutting down and stove cooling is finished.

5.6. OPERATING MODE

5.6.1. MANUAL MODE (*MANU*)



In this mode **you can adjust heating power (*Fire: 1 – 5*) and warm air ventilator speed (*Fan: 1 – 5*).**

If the system is in automatic mode, pressing the third icon from the left will change the mode into manual.



5.6.2. AUTOMATIC MODE (*AUTO*)



25°C



Unlike the manual mode where you can adjust the heating power, in automatic mode you **can adjust the room temperature (*Temperature: 5 – 40°C*).**


If the system is in manual mode, pressing the third icon from the left will change the mode into automatic.



The room temperature is measured by a probe (P-figure 28) – black wire, situated on the stove backside, next to the activation switch. In order to more realistic room temperature measuring, it is necessary to **ensure that the probe is located away from any heat influence.**



You can connect the stove also to the **room thermostat**. Thermostat wires must be attached to the **"THERM" connection** on the back of the stove. In this case the probe (P) at the back of the stove will no longer have its function. The authorized individual must activate the thermostat in the technical menu.



If your system is linked with a thermostat, instead the temperature icon you'll find the "Therm" icon. When the letters are in red color, means it's closed contact, otherwise when they are grey means open contact.



CLOSED contact = temperature is not reached, the power increase!
OPEN contact = temperature is reached, the power decrease!





Please note that, in AUTO mode or if the room thermostat is enabled, the electronics will reduce the stove heating power at a temperature (room or water) which was first reached.



The stove will automatically change the heating power to keep the set temperature constant. Warm air ventilator speed changes automatically (*Fan:A*) to accommodate current heating power.



The stove will operate on maximum power until the set temperature is achieved. **Once the set temperature is achieved, the stove will gradually reduce the heating power** (with a delay of 2 minutes between 2 powers) **to minimum.** When the temperature drops below the set value, **the stove gradually returns to maximum heating power** (with a delay of 1 minute between 2 powers) **to reach the set temperature.**



After each ignition, the stove returns to the operating mode selected before the last shut down!

5.6.3. ECO MODE (ECO)

This mode is similar to automatic mode. Unlike the automatic mode, which reduces the heating power to minimum once the set temperature is achieved, ECO mode TURNS OFF the stove once the set room temperature is achieved. When the room temperature drops for a value which is factory set to **3°C** and after a predetermined stove cooling (shut down) period has elapsed, **THE STOVE IS AUTOMATICALLY RESTARTED.**

E.g.: If the current room temperature is 18°C, and you have set the temp. on the control panel to 23°C, the stove will operate on max. heating power (*Fire 5*). Once the set temp. is reached (23°C + 1 = 24°C), the stove goes to min. power (*Fire 1*). Now (from detection of 24°C) the electronics start to countdown the time (factory set) of **20 min**. If during this time (20 min) the temperature is still more than 23°C, the stove automatically shuts down (**SHUT DOWN**).

When the stove begins with shut down, the electronics start to countdown the time (factory set) of **40 min**. At the end of this period (40 min) the electronics control the room temperature. If the room temperature is constantly more than 23°C (**set**) **MINUS 3°C** (factory set) → so if temperature is more than 20°C, the stove doesn't start again. **The stove will start (IGNITION → ON) again only when: 40 min has passed AND the room temperature is LESS than 20°C** (e.g. 19°C).



This function can be found in **Settings** menu under **Eco**. You can activate this function by clicking on it OR clicking inside the empty box to get the green checkmark. **Eco** appears on the display - see (13) on *Figure 22b*. To turn off Eco mode follow the same procedure.



- **ECO mode remains active until it is set off from the Settings menu!**
- **This operating mode is recommended only for stoves installed in well-insulated rooms with insignificant heat losses!**
- **Please note that after several re-ignitions and because of unburned pellets (ash) in the burner pot, could result in bad ignition of new inserted pellets → possible release of smoke into the room! Therefore please clean the burner pot if necessary.**
- **In manual mode (MANU), it is possible to enable ECO only if the room thermostat is active - otherwise, AUTO must always be active!**



5.6.4. WARM AIR FAN (FAN)



As previously mentioned, the stove is equipped with a warm air fan, which **heats the space through grid on the stove front side**. You can set **5 different blowing speeds** depending on the operating mode the stove is in (AUTO or MANU).

In AUTO mode, the fan speed is related to the stove heating power. E.g. if the heating

| | | | |
|------|---------|------------|---|
| MANU | Fire: 1 | Fan: 1 - 5 | ✓ |
| | Fire: 2 | Fan: 2 - 5 | |
| | Fire: 3 | Fan: 3 - 5 | |
| | Fire: 4 | Fan: 4 - 5 | |
| | Fire: 5 | Fan: 5 | |
| AUTO | Fire: 2 | Fan: 1 | ✗ |
| | Fire: 3 | Fan: 1 - 2 | |
| | Fire: 4 | Fan: 1 - 3 | |
| | Fire: 5 | Fan: 1 - 4 | |
| | Temp: | Fan: A | |
| | Temp: | Fan: 1 - 5 | ✗ |

Table 5



power is 3 (*Fire: 3*), the fan is automatically set to speed 3; if the heating power is 5 (*Fire: 5*), the fan speed is 5, etc. The control panel displays **Fan:A**.

The speed adjustment is simply achieved 1-2-3-4-5-A by sliding with the finger on the screen.



- **it is not recommended to set fan speed smaller than the set heating power!**
- **otherwise, it comes to stove overheating and alarms A04 or A03 will occur. The ultimate consequence is loss of warranty on the product and damage on the electronics!**

5.7. ADVANCED FUNCTIONS

5.7.1. AUTOMATIC SHUT DOWN (SLEEP)



This function is used **to set (programme) the time when you want the stove to turn off**. The function **Sleep** is displayed on the control panel only if the stove is activated or in the ignition process.

Available values can be set beginning with the first ten minute interval after the current time (e.g. if the current time is 15:43, the first value you can set is 15:50), and the maximum is 23 h and 50 min after the current time.



This function is set if you click on the "**Zz**" icon on the screen. Once Sleep function is set, it appears on the START screen icon "**Zz**" bolded.




Figure 30

5.7.2. TIMER (CHRONO)



This function allows you to set **6 different on/off daily schedules**. Each schedule can be assigned to one or more days of the week, which ensures a **very flexible and easily adjustable weekly schedule** which suits all your needs.

This function is set if you click on the **"CLOCK" icon** on the screen.





Figure 31

Available Chrono functions are listed in *table 6*, in the same order as they appear on the display.

Table 6

| Function | Description |
|--------------|--|
| Enable | "1" - On / "0" - Off |
| Load Profile | Loading pre-set defined templates of weekly profiles; P1 – P10 (see <i>chapter 5.7.2.1.</i>) |
| Reset | Cancelling all current settings; confirmation is needed (key ) to return to default values |
| | P1 P2 P3 P4 P5 P6 |

Setting the **6 available programmes** is executed in a new menu, with the list of parameters as described in the following table.

Table 7


| Function | Value |
|-------------|----------------------------|
| Enable | "1" - On / "0" - Off |
| Start | 0-23 (15 minute steps) |
| Stop | 0-24 (15 minute steps) |
| Air Temp. | 5-40°C (18°C by default) |
| Water Temp. | 30-85°C (60°C by default) |
| Fire | 1-5 (3 by default) |
| Days | Mo, Tu, We, Th, Fr, Sa, Su |

In order to activate each daily schedule, start and stop hours need to be set,

in order to define the time interval.



- **CHRONO** function can be programmed (activated) or deactivated whether the stove is in OFF-state or in ON-state!
- If you have activated any of the Programmes, "CLOCK" icon will appear bolded on the control panel START screen!



Choose the Start and Stop Time, choose the Fire (power) level, the air temperature, the water heating temperature. Then you have to choose which days you want to apply this program. At the end **remember to enable the program**, clicking on the *Enable* button and **save it clicking the green check button on the upper right corner.**

Recommendations:

- **activation and deactivation time intervals should include one day only, from 00:00 to 24:00h, which means that the stove can't work from Friday to Saturday, for instance !**

- EXAMPLE: ⇒ start at 06:00 h } ✓
 ⇒ stop at 17:00 h }
 ⇒ start at 21:00 h } ✗
 ⇒ stop at 05:00 h }



✗ WRONG

→ SOLUTION:

Prog1: Start 21:00, Stop 00:00

Prog2: Start 00:00, Stop 05:00

⇒ the programme will use the lower value (05:00 h) as activation !


- according to previous example, **the stop time must be greater than start time!**
- **before using the Chrono function, you should set the current day and hour (if you still haven't) following instructions in *chapter 5.4.1. !***
- for the Chrono function to work, **it needs not only be programmed, but also activated (ENABLE) as shown in *figure 31.***



5.7.2.1. WEEKLY PROFILES

A group of 10 weekly profiles (programmes) for quick setting of on/off stove use times is available on the control panel. Each profile is defined with start/stop times per particular days. **Once you have selected a particular profile, you**

can freely change all the parameters that define it. You can see the



selection procedure in *figure 33* and the list of available pre-set default profiles in *table 8*.

ON OFF

Table 8

| P. | Days | Scheduling | | | | | | | | | | | | | | | | | | | | | | | |
|----|-------|------------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| | | 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 | 08 | 09 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 |
| 1 | Mo-Fr | | | | | | | | | | | | | | | | | | | | | | | | |
| | Sa-Su | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Mo-Fr | | | | | | | | | | | | | | | | | | | | | | | | |
| | Sa-Su | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Mo-Fr | | | | | | | | | | | | | | | | | | | | | | | | |
| | Sa-Su | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Mo-Fr | | | | | | | | | | | | | | | | | | | | | | | | |
| | Sa-Su | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Mo-Sa | | | | | | | | | | | | | | | | | | | | | | | | |
| | Su | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Mo-Fr | | | | | | | | | | | | | | | | | | | | | | | | |
| | Sa-Su | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Mo-Fr | | | | | | | | | | | | | | | | | | | | | | | | |
| | Sa-Su | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Mo-Fr | | | | | | | | | | | | | | | | | | | | | | | | |
| | Sa-Su | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Mo-Fr | | | | | | | | | | | | | | | | | | | | | | | | |
| | Sa-Su | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Fr | | | | | | | | | | | | | | | | | | | | | | | | |
| | Sa-Su | | | | | | | | | | | | | | | | | | | | | | | | |



i If some Chrono programme is active, and you want to pre-turn on / off the stove, change AUTO/MANU mode, **the command (change) that you created has the advantage ahead of Chrono.** *Example:* the Chrono is set to turn on at 8:00, but you choose to turn on the stove at 7:00. The stove will be normally turned on at 7:00, and ignition at 8:00 will be ignored. In any case, the Chrono programme will remain unchanged (turn on at 8:00).



i If you want to change some parameter such as heating power (*Fire*) or temperature (*Temp*), Chrono will accept the change you have made **BUT after 15 minutes the stove will continue to operate according to the Chrono programme.** *Example:* the stove is working on *Fire:1* (Chrono), but you choose to change the heating power to *Fire:3*, after 15 minutes the stove will return to *Fire:1*.

5.8. SETTINGS



To the settings menu we come by clicking on the **gear icon** - see (10) on *Figure 22a*. The following table lists various options in the order they appear on the screen, together with their values.

Table 9

| Option | Value |
|--------------------|---|
| Language | ENG-ITA-POL-ROU-HRV-SLO-SRB-BUL-RUS-TUR-GRE-HUN-NED-POR-DEU-ESP-FRA |
| Eco | <input checked="" type="checkbox"/> / <input type="checkbox"/> |
| Back light | On - 1200 sec (10 sec steps) |
| °C/°F | Auto / °C / °F |
| Combustion recipes | <i>see Chapter 5.8.2.</i> |
| Charge Pellet | <i>see Chapter 5.8.3.</i> |
| Cleaning | <i>see Chapter 5.8.4.</i> |
| Start Pump | <i>see Chapter 5.8.5.</i> |



Figure 34

5.8.1. BACKLIGHTING

Backlight option **enables you to set the time and the used level of backlight on the START screen**. If you choose ON, the screen will be lighted all the time; other data set the time interval in which the backlight is reduced.

5.8.2. COMBUSTION RECIPES (*PELLET AND AIRFLOW*)



This option allows you to alter two pieces of data – pellet (fuel) feeding and combustion airflow. **You can regulate the percentage of function.**



Depending on pellet type (quality) your stove will distribute more or less pellets. To determine how larger/smaller your dosage is from default factory settings, we advise you to apply the following procedure (**BEFORE FIRST IGNITION**):



1. Put the few pellets with the hand in the tank and run the option **Charge Pellet** (see Chapter 5.8.3.)
2. **Be sure that the pellet feeder spiral is COMPLETELY FILLED WITH PELETS - pellets have started to fall constantly in the burner pot**
3. Turn off the option *Charge Pellet*, empty the burner pot, fill the tank with 2-3 kg of pellets and restart the option *Charge Pellet*
4. Note the dosage start time and allow the pellet feeder to operate for exactly 5 minutes
5. After 5 minutes, turn off the option *Charge pellet*
6. Remove the pellets from the burner pot and weigh them on the kitchen scale
7. If the pellet quantity deviates from the default factory setting, it is necessary to undertake dosage correction +/- ("**Pellet**" correction)

Table 10

| Pellet quantity | Dosage (<i>Pellet</i>) correction |
|--------------------|-------------------------------------|
| >350 g | Reduce the dosage (e.g. -5) |
| 320 – 350 g | +/- 0 (no correction needed) |
| <320 g | Increase the dosage (e.g. +3) |

PELLET DOSAGE DEFAULT FACTORY SETTING IS FOR **NOMINAL STOVE POWER, WHICH IS ALSO THE MAXIMUM POWER! THE CUSTOMER IS NOT ALLOWED TO EXCEED THE NOMINAL POWER!!!**



In case of any problems in stove operations caused by pellet quantities (too much or too little), you can regulate pellet dosage and airflow directly on the control panel. The problems can be subdivided into two categories:

INSUFFICIENT FUEL

- the stove is not capable of developing suitable flame which is weak even when the stove is set to maximum heating power

INSUFFICIENT AIRFLOW

- the glass becomes stained easily and is almost completely dark
- a large amount of smoke in firebox during ignition phase

EXCESSIVE FUEL

- the stove develops a strong flame even when it is set to minimum heating power
- during ignition phase, the flame is smothered in the burner pot and therefore a large amount of smoke is developed in the firebox

EXCESSIVE AIRFLOW

- on minimum power, the flame has a tendency of extinguishing and **A02 alarm occurs**



Values for combustion recipes regulation are listed in the following table.

| Table 11 | Combustion recipes | Value |
|----------|--|-----------|
| | Pellet (<i>regulating the pellet dosage during startup / shutting down / stove on phase</i>) | -10 ÷ +10 |
| | Airflow (<i>regulating the combustion airflow during startup / shutting down / stove on phase</i>) | |

Example:



- **PELLET:** **increase** the percentage value by 1,6 % OR **decrease** the percentage value by 3,3 %

- E.g. +3 → +4,8% = for 4,8% more pellet dosage; max $10 \times 1,6 = 16\%$
-6 → -19,8% = for 19,8% less pellet dosage; max $10 \times 3,3 = 33\%$



- **AIRFLOW:** **increase** the percentage value by 3,3 % OR **decrease** the percentage value by 1,6 %

- E.g. +3 → +9,9% = for 9,9% more air quantity; max $10 \times 3,3 = 33\%$
-6 → -9,6% = for 9,6% less air quantity; max $10 \times 1,6 = 16\%$

5.8.3. PELLET FEEDER FILLING (*CHARGE PELLET*)



This option is available **only if the stove is turned off**, and its purpose is pellet dosage into the firebox. You can activate this option by clicking on it OR set the button on "I".

5.8.4. BURNER POT CLEANING (*CLEANING*)



This option is available **only if the stove is turned off**. The flue gases suction ventilator is set to its maximum speed to blow away ash and soot from the burner pot. You can activate this option by clicking on it OR set the button on "I".



The stove is also equipped with a function that allows **automatic cleaning of the burner pot after a certain period of pellets burning**. This process can be recognized by a big and noisy flame. **After a few seconds the stove will continue to operate normally.**

5.8.5. SWITCHING ON THE PUMP (START PUMP)

This option is available **only if the stove is turned off**, and its purpose is check the operation of the pump for the circulation of water. You can activate this option by clicking on it OR set the button on "I".



5.9. TECHNICAL MENU

The sole **purpose** of this menu is **servicing** and it includes all the **data** that **can be altered exclusively by authorised technical personnel**. Access to this menu is protected by a password.

After 2000 working hours on the display will appear the message "**Warning**" OR "**Service**" which means that it **is necessary to make a regular service on the stove** (at user's expense) ⇒ from the service technician you must get a "*Certificate of executed stove service.*"



NOTE: If after the appearance of this message you don't call the authorized technical staff, you will lose the warranty on the product! Until the arrival of the technician, the stove can still be used normally!



5.10. USER INFO MENU



This menu includes **the list of values and functions related to the stove operations control**. None of the displayed values can be altered!

To the User Info menu we come by clicking the **"i"** **letter icon** - see (11) on *Figure 22a*.




Figure 35

The following table lists different data in the menu in order of their appearance with their available values.

Table 12

| Function | Value |
|-----------------------|--|
| Control Board Code | 000000 |
| Security Code | 000000 |
| Display Code | 000000 |
| Parameters Code | 000000 |
| Functioning Time | 000000 – 999999 h |
| Service Time | 0000 – 9999 h |
| Service | (phone number) |
| Extractor 1 Rpm* | 0000 – 2750 rpm |
| Measured Airflow* | 000 – 400 lpm |
| Consumption Pellet** | 0.0 kg OR 0.0 kg/h* |
| Fumes Temperature* | 000 – 300°C |
| Pellet Feeder 1 Time* | 0.1 – 12 sec |
| Activation Fan1* | 500 - 1000 |
| Ignitions Number | (total number of the stove life ignitions) |

Very important data which service technician can ask you for, after some “Warning” or “Alarm A0x” appearance on the control panel.

* depending on the current operation of the pellet stove

** if you click on this data the value will change from kg to kg/h and vice versa


kg = calculated total consumption from the first ignition

kg/h = consumption depending on the current operation of the pellet stove

5.11. ALARMS



When an alarm condition occurs, alarm is displayed on the control panel display (Figure 36) ⇒ **the stove automatically shuts down**. In this situation, **it is not possible to access the start menu**, and the stove status cannot be altered **before issuing an order to unblock the alarm**.



The bottom line on the display indicates alarm type and short description. **Purple icon stops the alarm sound. If you press the green icon longer than 2 seconds, the alarm will be unblocked (RESET), but only if alarm cause is removed.**



If you **press the upper left** (see *Figure 36*) **key**, while the alarm screen is displayed, **you access the start screen** where you can correct the potential errors.

Table 13

| Code | Alarm type | Informations |
|------|--|--|
| A01 | Ignition Failed <ul style="list-style-type: none"> - default factory setting prerequisites for regular ignition not met - pellet tank is empty - burner pot is polluted or wrongly set into the casing - igniter does not heat up - pellet feeder is clogged | <ol style="list-style-type: none"> 1. <u>reset the alarm</u> and restart 2. check the pellet level in the tank 3. empty the tank and clean the pellet feeder spiral 4. check if the burner pot is properly set and cleaned – read <i>Chapter 6.1</i>. 5. turn on the stove and check if the igniter heats |
| A02 | Flame Shut Down <ul style="list-style-type: none"> - pellet feeder "running dry" or clogged - lack of fuel in the firebox - flue gases fan excessive speed OR too low flue gases temperature | <ol style="list-style-type: none"> 1. <u>reset the alarm</u> and restart 2. check the pellet level in the tank 3. clean the pellet feeder spiral 4. fill the pellet tank 5. see <i>chapter 5.8.2</i>. 6. technician must reduce the fan speed OR increase the temperature |

| | | |
|-------------------|--|--|
| <p>A03</p> | <p>Pellet Tank Over-Temp. - stove body overheating - stove operating on maximum power too long or is poorly ventilated, i.e. warm air fan operates on too low speed</p> | <ol style="list-style-type: none"> 1. <u>reset the alarm</u> and restart 2. reduce the stove heating power and increase warm air fan speed 3. clean the central flue gases channel according to <i>chapter 6.8.</i> |
| <p>A04</p> | <p>Fumes Over-Temperature - stove body overheating - stove operating on maximum power too long or is poorly ventilated, i.e. warm air fan operates on too low speed</p> | <ol style="list-style-type: none"> 1. <u>reset the alarm</u> and restart 2. reduce the stove heating power and increase warm air fan speed 3. clean the central flue gases channel according to <i>chapter 6.8.</i> and the plate in the firebox-Figures.45c and d |
| <p>A05</p> | <p>Fumes Pressure Switch Alarm - flue gas channels or chimney clogged - chimney diameter larger than prescribed - firebox door open or the seal damaged - pellet feeder spiral clogged - improperly executed installation (chimney not properly sealed) - chimney is not insulated according to the instructions - burner pot improperly installed into the casing</p> | <ol style="list-style-type: none"> 1. <u>reset the alarm</u> and restart 2. repeat ignition 4-5 times 3. while the stove is shutting down (flue gases fan rotating at maximum speed), burn some paper and put a fistful of pellets into the firebox to warm the chimney 4. check and clean the chimney and flue gas channels 5. connect the stove to a chimney with prescribed diameter 6. check the firebox door and replace the gasket 7. remove all the pellets from the tank and clean the pellet feeder spiral 8. properly set the burner pot into the casing |
| <p>A06</p> | <p>Combustion Airflow Alarm</p> | <ol style="list-style-type: none"> 1. <u>reset the alarm</u> and restart 2. check burner pot cleaning / air intake / chimney |
| <p>A07</p> | <p>Door Open - uncontrolled entry of air into the firebox - flue gas channels or chimney clogged - airflow sensor is polluted</p> | <ol style="list-style-type: none"> 1. <u>reset the alarm</u> and restart 2. check if door is closed and replace the door gasket if necessary 4. check and clean the chimney and central flue gas channel - <i>chapter 6.8.</i>; clean the sensor-chapter 6.10. |
| <p>A08</p> | <p>Fumes Extractor Error</p> | <ol style="list-style-type: none"> 1. <u>reset the alarm</u> and restart 2. check and clean the chimney and central flue gas channel - <i>chapter 6.8.</i> |
| <p>A09</p> | <p>Fumes Temp. Sensor Error</p> | <ol style="list-style-type: none"> 1. <u>reset the alarm</u> and restart 2. too low temperature of the surrounding area |

| | | |
|-----|--|---|
| | | 3. contact an authorized technician |
| A10 | Pellet Igniter Error | 1. <u>reset the alarm</u> and restart 2. contact an authorized technician |
| A11 | Pellet Feeder Error | 1. <u>reset the alarm</u> and restart 2. contact an authorized technician |
| A13 | Electronic Motherboard Error - motherboard overheating | 1. <u>reset the alarm</u> and restart 2. reduce the stove heating power and increase warm air fan speed |
| A18 | Water tank over-temperature - stove operating on maximum power too long or is poorly ventilated, i.e. warm air fan operates on too low speed - system is oversized, improperly performed installation of central heating - too small water flow - pump rotor is blocked - too much fuel in the firebox - radiators closed or not properly deaerated | 1. <u>reset the alarm</u> and restart 2. reduce the stove heating power and increase warm air fan speed 3. dimension the central heating system according to professional standards and DIN 4751 norm – part 1 for open systems, i.e. DIN 4751 – part 2 for closed systems 4. increase water flow by adjusting the pump speed 5. unblock (clean) the pump rotor according to <i>chapter 4.6.1.</i> , point 3 6. make sure that all the radiators are opened and well deaerated |

6. CLEANING AND MAINTENANCE

Never undertake cleaning and maintenance procedures until the stove is completely cold and turned off!



Recommended cleaning and maintenance intervals of SENKO pellet stoves are listed in the *Table 14*.



The stove does not require excessive maintenance provided you use high-quality, certified pellets (see *chapter 2*)!

6.1. BURNER POT



Prior to every stove activation use appropriate tool to remove the burner pot from the firebox and use a vacuum cleaner with a container to **remove the ash in the burner pot and below the burner pot.**



It is important that the ash is completely cold during vacuuming!





Figure 37




Figure 37a


A properly cleaned burner pot guarantees proper functioning of the stove. Should you, during burner pot feeding phase, notice that apart from pellets, **a lot of sawdust and dust is falling into the burner pot**, you must clean the pellet tank as soon as possible. Otherwise, **dangerous backfire towards the pellet tank may occur**. If the described situation occurs again after you have cleaned the tank, it means you are using low quality pellets. Use pellets described in *chapter 2!*



Once a day (depending on pellet quality – ash content) **BE SURE TO clean the burner pot!**



Every time you remove the burner pot, make sure you properly install it back into the casing - **OBLIGATORY CHECK THAT THE IGNITER TUBE OVERLAPS WITH THE HOLE ON THE LOWER PART OF THE BURNER POT** – see *Figure 37a!*



It is also possible, depending on the pellet type and quality, that solid ash deposits accumulate and stick around or on the pot. These must be cleaned *if necessary* using appropriate tools! **All holes in the burner pot must be clean and passable!**

IN CASE OF WEAR-DOWN OR DAMAGE, IMMEDIATELY REQUEST AN AUTHORIZED MAINTENANCE TECHNICIAN TO REPLACE YOUR BURNER POT (REPLACEMENT IS NOT COVERED BY WARRANTY SINCE THIS IS A MATERIAL PRONE TO WEARING DOWN).



6.2. HEAT EXCHANGER

If don't, alarm A04 will occur!!!


Perform the **heat exchanger cleaning every 2-3 days**. It is sufficient to **pull and push the lever** located on the **stove front side** (between the hot air expulsion grids) for **5-6 times** – see **Figure 38**. This way you clean the external pipe surface from soot.



It is important to perform this procedure only if the stove is cold. Should you try to clean during regular stove operation, it is possible for the lever to get stuck due to material dilatation effect. Also, **the lever is hot during regular stove operation so there is danger of burns**.



The following figure demonstrates the described cleaning procedure



It is **FORBIDDEN** to lean on the lever and hang the heavy objects on it! It is **FORBIDDEN** to dry a laundry on the lever!



NOTE: the lever is located only at the stove P8-SLIM!



6.3. ASH PAN - **only on some models!**



Figure 39

Perform the ash pan cleaning **every 2-3 days** also, depending on the pellet type, i.e. the quantity of produced ash.

Perform the procedure **with a vacuum cleaner with a container, only if the ash is cold.**



Once you have performed the cleaning, properly put the ash pan back into the casing frame!

IN CASE OF WEAR-DOWN OR DAMAGE, IMMEDIATELY REQUEST AN AUTHORIZED MAINTENANCE TECHNICIAN TO REPLACE YOUR ASH PAN (REPLACEMENT IS NOT COVERED BY WARRANTY SINCE THIS IS A MATERIAL PRONE TO WEARING DOWN).



6.4. DOOR GLASS

Firebox door are equipped with fire resistant glass (750°C). The glass is, regardless of the high resistance to heat, sensitive to impact force.

The glass is self-cleaning, i.e., during regular stove operation, a light air current touches the inner surface of the glass, significantly reducing ash and dirt deposits.



If necessary, **clean the channel behind the sheet metal** (marked in the picture) so that the air required for glass cleaning has its own function.



Figure 40

It is possible for glass to become stained during several hours of regular stove operation, **depending on used pellet type and chimney underpressure**. In that case **clean the glass using a cotton cloth, newspaper or a dishtowel moisturized with a glass cleaning liquid** (*figure 40*). Make sure to perform the described procedure only while the stove is cold.

6.5. EXTERNAL SURFACE

Use a **soft cloth with neutral cleaning liquid** for cleaning.

Never use metallic sponges and/or similar sponges, lest you damage the surface!

PAINTED SURFACES DO NOT CLEAN WITH ABRASIVE CLEANING AGENTS!



6.6. PELLETTANK



Figure 41

Periodically (**at least once a month**) completely empty the pellet tank (by using a vacuum cleaner) - **vacuum the dust and sawdust that has accumulated inside!**

6.7. FIREBOX DOOR GASKET

The gasket guarantees that the stove is hermetically sealed, and consequently, proper stove functioning. **Be sure to periodically control it** – in case of wear-down or damage, it needs to be replaced by an authorized individual.



6.8. CENTRAL FLUE GAS CHANNEL

If don't, alarm A07 or A04 will occur!!!



Central flue gases channel must be cleaned once a month because the accumulated soot clogs the normal flow of flue gases.




CLEANING SEQUENCE: **1.** channel cleaning according to the *Figure 43*.
2. channel cleaning according to the *Figure 42*.



Unscrew the bolts to **remove the plate located under the firebox**. Use the vacuum cleaner to clean the combustion residues accumulated at the bottom of the channel.








Figure 42



replace the plate gasket as needed !



It is also necessary to **remove the upper stove lid**, and by unscrewing the bolts **remove the plate located under the lid**, then **remove the *turbulators*** (spirals) and properly clean them with a brush.

**Figure 43**

In places where it was a gasket, it is necessary to put the new one (heat-resistant) to ensure a good seal!



When cleaning the upper side of the stove, and if the firebox door or the lid under the firebox is opened, **it is possible that a fine ash comes out from the tubes!**



After cleaning, it is necessary to assemble everything in reverse order.

6.9. OUTPUT FLUE GAS CHANNEL



At the beginning of every heating season clean the flue gases output channel, i.e. the chimney. **The chimney must be regularly maintained by an authorized individual** in order to ensure proper stove functioning. Skipping the annual chimney maintenance is grounds for cancelling product warranty.

6.10. INPUT PRIMARY AIR CHANNEL




At the beginning of every heating season (and may also more frequently) clean the **primary air inlet channel (Ø 50 mm on the stove backside)** from dust.

Check and wipe the **airflow sensor** – see the arrows on the sensor!



OBLIGATORY clean the sensor when an **alarm A07** occurs!

Figure 44



6.11. FIREBOX



Remove the dust or potential ash traces that have accumulated during regular stove operation **twice a week** (see *figure 45a* and *b*).

Also it is necessary to **remove and clean the plate in the firebox** (see *figure 45c* and *d*).

If don't, alarm A04 will occur!!!





Figure 45



It is also important to occasionally clean **ash residue between igniter support tube and igniter** which is located in the firebox within the burner pot. It is important to enable free circulation of air around the igniter, which prevents the igniter from burning out.



Igniter must always be placed in the middle of the supporting tube!



6.12. ELECTRONIC COMPONENTS



We recommend **annual inspection of all electronic components by an authorised individual**. The inspection consists of visual and functional inspection of internal stove parts (motors, safety devices and similar) and their replacement if necessary.



During periods of inactivity the stove must be unplugged and located in a dry environment. To ensure even higher level of safety, especially children, we recommend to disconnect the electric cable from the stove and store it in a safe location.



Should you, during stove reactivation, fail to turn the stove on, it is possible that the **fuse (max 6,3A and 250 V)** located on the switch at the stove backside has blown. In that case, it is necessary to replace it by using the screwdriver to **pull out the plastic part in the centre of the switch** and to remove the fuse (*figure 46*).



Figure 46

Recommended cleaning and maintenance intervals of SENKO pellet stoves are listed in the following table.



| PART | CLEANING AND MAINTENANCE INTERVAL | | | |
|--|-----------------------------------|----------|---------|--------|
| | 1 day | 2-3 days | 30 days | 1 year |
| Burner pot (see chapter 6.1.) | ✓ | | | |
| Heat exchanger (see chapter 6.2.) | | ✓ | | |
| Ash pan (see chapter 6.3.) | | ✓ | | |
| Door glass (see chapter 6.4.) | | ✓ | | |
| Firebox (see chapter 6.11.) | | ✓ | | |
| Pellet tank (see chapter 6.6.) | | | ✓ | |
| External surfaces (see chapter 6.5.) | | | ✓ | |
| Central flue gases channel + turbulators (see chapter 6.8.) | | | ✓ | |
| Igniter support tube (see chapter 6.11.) | | | ✓ | |
| Input primary air channel (see chapter 6.10.) | | | | ✓ |
| Output flue gas channel – chimney (see chapter 6.9.) | | | | ✓ |
| Ventilator and pellet feeder motors and other electronic equipment | | | | ✗ |

✗ these actions of cleaning and maintenance can be performed only by authorized personnel of pellet stove producer

NOTE: The actions listed in the table above can be performed even more frequently (if necessary), depending on the quality of pellets that you use!

7. MALFUNCTIONS / CAUSES / SOLUTIONS



All potential repairs must be executed exclusively by an authorised individual while the stove is cold and unplugged!

| PROBLEM | POSSIBLE CAUSE | SOLUTION |
|--|--|--|
| Pellets are not inserted into the firebox | <ul style="list-style-type: none"> ◆ pellet tank is empty ◆ pellet feeder is blocked with sawdust or foreign bodies ◆ pellet feeder motor is malfunctioning ◆ defective motherboard | <p>⇒ fill the pellet tank</p> <p>⇒ empty the pellet tank and manually clean the pellet feeder spiral and the dosing tube. After cleaning, check the dosage - enable option <i>Charge pellet</i></p> <p>⇒ check the motor and replace it if necessary</p> <p>⇒ check the motherboard and replace it if necessary</p> |
| The fire is extinguished or the stove ceases operation with no reason | <ul style="list-style-type: none"> ◆ pellet tank is empty ◆ pellets are not inserted into the firebox ◆ alarm is appeared on the control panel ◆ timer (<i>chrono</i>) is active ◆ firebox door is not properly closed or the gasket is damaged ◆ pellets used do not meet the criteria for proper stove functioning ◆ improper pellet dosage ◆ firebox polluted ◆ primary air inlet channel clogged ◆ chimney clogged ◆ flue gases ventilator motor malfunctioning | <p>⇒ fill the pellet tank</p> <p>⇒ see previous problem</p> <p>⇒ allow the stove to cool completely, reset the alarm (see <i>chapter 5.11.</i> and <i>Table 13</i>) and repeat stove ignition process</p> <p>⇒ check timer activation</p> <p>⇒ close the door or replace the gasket with a new original</p> <p>⇒ replace the pellet type with one recommended in <i>chapter 2.</i></p> <p>⇒ correct dosage according to <i>chapter 5.8.2.</i></p> <p>⇒ clean the firebox according to <i>chapter 6.11.</i></p> <p>⇒ clean primary air intake pipe (∅ 50 mm) according to <i>chapter 6.10.</i></p> <p>⇒ clean the chimney</p> <p>⇒ check the motor and replace it if necessary</p> |
| The stove works for a few minutes and then shuts down | <ul style="list-style-type: none"> ◆ activation sequence not completed ◆ chimney clogged ◆ alarm is appeared on the control panel ◆ combustion air supply inadequate ◆ temporary failure of electricity supply ◆ pellet igniter malfunctioning | <p>⇒ repeat stove ignition process</p> <p>⇒ clean the chimney</p> <p>⇒ allow the stove to cool completely, reset the alarm (see <i>chapter 5.11.</i> and <i>Table 13</i>) and repeat stove ignition process</p> <p>⇒ clean primary air intake pipe (∅ 50 mm) according to <i>chapter 6.10.</i></p> <p>⇒ when electricity is restored, the stove will be cooled down and switched off; repeat stove ignition</p> <p>⇒ check the igniter and replace it if necessary</p> |
| Pellets accumulate in the burner pot, the | <ul style="list-style-type: none"> ◆ insufficient combustion air ◆ holes on the burner | <p>⇒ clean primary air intake pipe (∅ 50 mm) according to <i>chapter 6.10.</i></p> <p>⇒ clean the burner pot and entire</p> |

| | | |
|--|---|---|
| <p>flame is weak and the glass stains</p> | <ul style="list-style-type: none"> ◆ pot bottom are clogged ◆ firebox door gasket is damaged ◆ moist and inadequate pellets ◆ chimney clogged or is not installed according to instructions ◆ flue gases ventilator motor malfunctioning | <p>firebox</p> <ul style="list-style-type: none"> ⇒ check the door gasket and replace it if necessary ⇒ replace the pellet type with one recommended in <i>chapter 2</i>. ⇒ clean the chimney and check if it is installed according to instructions ⇒ check the motor and replace it if necessary |
| <p>Flue gases suction ventilator does not work</p> | <ul style="list-style-type: none"> ◆ no power supply to the stove ◆ motor malfunction ◆ motherboard malfunction | <ul style="list-style-type: none"> ⇒ check the supply voltage and the fuse on the switch at the backside of the stove ⇒ check (and clean) the motor and replace it if necessary ⇒ replace the motherboard |
| <p>Warm air ventilator works continuously</p> | <ul style="list-style-type: none"> ◆ fumes temperature probe malfunction ◆ ventilator malfunction | <ul style="list-style-type: none"> ⇒ check and replace the probe if necessary ⇒ check the motor and replace it if necessary |
| <p>In automatic mode the stove always operates on maximum power</p> | <ul style="list-style-type: none"> ◆ temperature is set to maximum ◆ room temperature probe malfunction ◆ control panel malfunction | <ul style="list-style-type: none"> ⇒ reduce the temperature on the control panel or the thermostat ⇒ check and replace the probe if necessary ⇒ check and replace the control panel if necessary |
| <p>The stove cannot be turned on</p> | <ul style="list-style-type: none"> ◆ electric power supply to the stove reduced ◆ fuse blown | <ul style="list-style-type: none"> ⇒ check if the electric cable is connected to the stove backside and if the switch is in „I“ position ⇒ replace the fuse (<i>figure 46</i>) |
| <p>Pellets do not ignite</p> | <ul style="list-style-type: none"> ◆ burner pot polluted ◆ burner pot is not properly installed into the casing ◆ chimney and/or flue gas channels clogged ◆ pellet igniter does not heat up | <ul style="list-style-type: none"> ⇒ clean the burner pot from ash and unburned pellet residue ⇒ check and properly set the burner pot into the casing – see <i>figure 37a</i> ⇒ clean the chimney and/or flue gas channels according to <i>chapter 6.8</i>. ⇒ check and replace the igniter if necessary |
| <p>There is noise from the boiler</p> | <ul style="list-style-type: none"> ◆ insufficient water level in the central heating system ◆ insufficient water pressure in the central heating system ◆ improper central heating installation ◆ excessive water flow in the system ◆ air in the system | <ul style="list-style-type: none"> ⇒ refill the system with necessary amount of water to achieve 1 bar ⇒ increase water pressure to 1 bar ⇒ execute the central heating installation in accordance with professional standards and DIN 4751 norm - part 1 for open systems, i.e. 4751 - part 2 for closed systems ⇒ reduce the water flow by adjusting the number of pump rotations ⇒ deaerate the system properly |

| | | |
|--|---|--|
| Water leaking from the boiler (boiler condensation) | <ul style="list-style-type: none"> ◆ excessive water flow ◆ fuel too moist ◆ too low water return temperature ◆ boiler damaged | <ul style="list-style-type: none"> ⇒ reduce the water flow ⇒ use fuel as described in <i>chapter 2</i>. ⇒ it is mandatory to install the 3-way thermostat mixing valve ⇒ call an authorized maintenance technician |
| Outlet boiler water does not reach the required temperature | <ul style="list-style-type: none"> ◆ central heating system improperly dimensioned ◆ boiler is contaminated ◆ insufficient heating power ◆ pump is blocked ◆ radiators are not properly deaerated ◆ probe that measures the water temperature does not show the correct temperature | <ul style="list-style-type: none"> ⇒ dimension the central heating system according to professional standards and DIN 4751 norm – part 1 for open systems, i.e. DIN 4751 – part 2 for closed systems ⇒ check and clean the boiler ⇒ increase the stove heating power ⇒ adjust the water flow in accordance with the boiler thermal possibilities ⇒ clean the pump according to <i>chapter 4.6.1.</i>, point 3 ⇒ deaerate the radiators properly ⇒ replace the probe if necessary |



- **Procedures marked with bold must only be executed by personnel authorized by the manufacturer!**
- **Manufacturer bears no responsibility in case of failure to adhere with these procedures!**

8. TECHNICAL SUPPORT

Dear client,

If you were unable to find the solution to the malfunctions, that potentially developed while using your product, in the table above, please feel free to contact our complaint and support service:

- Tel: 00385 40 337 344
- Fax: 00385 40 337 906
- E-mail: info@senko.hr, podrska@senko.hr

WE'D LIKE TO TAKE THIS OPPORTUNITY TO REMIND YOU WHAT YOU NEED TO POSSES WHEN CONTACTING OUR COMPLAINT AND SUPPORT SERVICE:

Before you contact us, prepare the following documents:

- **purchase receipt with the date of purchase,**
- **warranty** (*at the back of this Manual*),
- **written installation report** (*at the back of this Manual*)
- **Instruction manual.**

The documents listed above are necessary to ensure the quickest and clearest removal of the occurring malfunction!

9. TECHNICAL DATA

| SENKO pellet stove | | P 8 AIR | P 10 WATER+AIR |
|---|--------------------------------|---------------|-------------------|
| Height, mm | | | 1145 |
| Width, mm | | | 905 |
| Depth, mm | | | 305 |
| Weight, kg | Stove with metal lining | 132 | 165 |
| | Stove with glass lining | 143 | 176 |
| Primary air intake, mm | | ∅ 50 | |
| Flue gases exhaust, mm | | ∅ 80 | |
| Nominal power (P _{nom}), kW | | 8 | 12 |
| Boiler, kW | | / | 10,3 |
| Room, kW | | 8,1 | 1,6 |
| Minimal power (P _{min}), kW | | 3,5 | 6,9 |
| Boiler, kW | | / | 3,1 |
| Room, kW | | 3,5 | 3,8 |
| Amount of water in boiler, L | | / | 20 |
| Operating pressure (max), bar | | / | 2,5 |
| Operating temperature, °C | | / | 80 |
| Fuel consumption at P _{nom} *, kg/h | | 1,9 | 2,7 |
| Fuel consumption at P _{min} *, kg/h | | 0,8 | 1,6 |
| Tank capacity, kg | | 16 | 15 |
| Efficiency at P _{nom} , % | | 85,71 | 90,7 |
| Efficiency at P _{min} , % | | 86,64 | 88,3 |
| Necessary chimney draught, Pa | | 12 | |
| Emission of CO in flue gases at P _{nom} (by 13 % O ₂), % | | 0,0303 | 0,0173 |
| Emission of CO in flue gases at P _{min} (by 13 % O ₂), % | | 0,0162 | 0,0067 |
| Emission of CO ₂ in flue gases at P _{nom} , % | | 9,8 | 8,3 |
| Emission of CO ₂ in flue gases at P _{min} , % | | 6,4 | 3,6 |
| Mean flue gas temperature at P _{nom} , °C | | 205 | 123 |
| Mean flue gas temperature at P _{min} , °C | | 140 | 81 |
| Flue gas mass flow at P _{nom} , g/s | | 6,2 | 10,0 |
| Flue gas mass flow at P _{min} , g/s | | 4,0 | 13,6 |
| Autonomy (operating time between re-fuelling) at P _{nom} *,h | | 8,2 | 5,6 |
| Autonomy (operating time between re-fuelling) at P _{min} *,h | | 19,5 | 9,4 |
| Electric energy consumption during activation, W | | 284,5 | 293,0 |
| Average electric energy consumption**, W/h | | 71,9 | 75,7 |
| Supply voltage and frequency | | 230 V / 50 Hz | |
| Energy efficiency class | | A+ | |

*variable data; may vary depending on the type of pellets used

**variable data; may vary depending on the stove operating conditions

- Technical specifications refer to use of pellets with quality ENplus-A1 and net calorific value of 4,9 kWh/kg
- Technical specifications are indicative and variable as such. The manufacturer reserves the right to alter any technical specification for the purposes of product improvement

10. TERMS OF WARRANTY

These terms of warranty are valid in all European countries where SENKO products are sold. The client addresses the vendor or the nearest authorized servicing agent for all complaints; providing the purchase receipt with the date of purchase, warranty sheet and installation report in the process.

WARRANTY DURATION

Manufacturer provides a **2 year** warranty for this product, starting from the date of purchase for all errors in production or construction materials. Electric and electronic components have a **1 year warranty**.

The manufacturer guarantees that the product was manufactured according to the EN 14785:2006 norm and that it complies with all the demands set by the norm. The user is obligated to adhere to the Instruction manual.

PARTS NOT COVERED BY THE WARRANTY

All parts susceptible to wear-down like vermiculite plates, burner pot, seals, glass, ash pan, electric cables, plasticized or ceramic parts and all the parts that can be removed from the firebox are an exception.

Vermiculite plates (possible discoloration and cracks). However, these changes do not compromise proper functioning of the product (as long as the plates are in the firebox) and they are not a motive for complaint.

Glass (door, coverings) - glass breakage or damage due to external influences and surface changes due to heat influences like flying ash or soot.

Changes in original colour of the materials due to high temperature conditions.

Seals - e.g. hardening or breaking due to heat or mechanic influences.

Material surfaces - frequent cleaning or cleaning with abrasive cleaning agents.

Parts exposed to excessive thermal influences - the burner pot, ash pan and the grid (the upper protective sheet) for warm air expulsion.

Heat exchanger (boiler) is not subject to the warranty in the event in which it is not secured with adequate anti-condensate circuit which guarantees a minimum return water temperature of at least 55°C.

REPAIRS

Possible repairs within the warranty will be executed within 30 days from the date of product delivery to the manufacturer. Should the repairs not be executed within 30 days from the delivery to the manufacturer, the product will be replaced with a new one. The manufacturer will notify the client about the executed repairs. The client is obligated to take over the product within 5 days from the repair completion.

EXPENSES

The manufacturer does not defray any delivery and return costs.

Prior to commencement of repairs within the warranty (for damages caused by incorrect use, stove transport and mounting), the manufacturer will notify the client about the repair price in written form. Once the client agrees, the manufacturer will execute the repairs and charge the client for the repairs.

REPLACEMENT PARTS

Original parts replaced within the warranty do not have to match the removed parts in external physical appearance, but they must match them in quality and functionality.

DISCLAIMER

The manufacturer is not responsible for product loss or damages due to theft, fire, vandalism or similar causes. Direct or indirect damages to the product resulting from inadequate transport are not covered by this warranty. The manufacturer is also not responsible for damages caused by chemical or electrochemical effects (harmful substances in the combustion air, etc.) resulting from improper product installation and failure to adhere to the Instruction manual.

ADDITIONAL TERMS

Small dimensional differences in construction materials and parts of the stove are not a reason for complaint. During the period in which the product was inefficient, we will not grant any compensation. This warranty applies only to the customer specified in the warranty sheet and cannot be transferred to others.

The warranty is void if the user has made any alterations to the product without notifying the manufacturer. If the user was negligent and performed maintenance on the wrong way. If the user is using fuel that is not compliant with the types and quantities indicated in this Manual.

The warranty is valid only if the product was installed by an authorized expert, and only with written installation report.

Possible disputes to be settled by the competent Court in Čakovec.

WARRANTY SHEET No.

STOVE FOR WOOD PELLETS :

P 8 AIR SLIM MODERN

P 10 WATER+AIR SLIM MODERN

SERIAL NUMBER: _____

DATE OF MANUFACTURE: _____

STORE NAME
AND ADDRESS: _____

CLIENT NAME
AND ADDRESS: _____

DATE OF PURCHASE: _____

STORE STAMP AND
VENDOR SIGNATURE: _____

Faulty product date of receipt:

Malfunction description (client):

Servicing agency comments:

Servicing completed:

date

Stamp and servicing technician
signature: _____

Faulty product date of receipt:

Malfunction description (client):

Servicing agency comments:

Servicing completed:

date

Stamp and servicing technician
signature: _____

Complaints within warranty – product
information:

COMPLETED BY THE CHIMNEY-SWEEPER**Chimney connection executed by the company:**Company/Business: _____ Person in charge: _____
stamp and signature

Street: _____ City: _____

Telephone: _____ Country: _____

Date: _____ Client signature: _____

Chimney

Type:

Dimensions (mm):

Height (m):

Draft (Pa):

Flue gases exit temperature (°C):

Last inspection date:

Number of connections:

Smoke venting pipe (if connected)

Cross-section (mm):

Length (m):

Number of elbows:

COMPLETED BY THE CENTRAL HEATING INSTALLATION CONTRACTOR**Central heating system connection executed by the company:**Company/Business: _____ Person in charge: _____
stamp and signature

Street: _____ City: _____

Telephone: _____ Country: _____

Date: _____ Client signature: _____

Open system yes noClosed system yes no

Connection execute in accordance with DIN 4751 yes no

Heated space volume (m³):Expansion tank volume (m³):

Pump type:

Water flow (m³/h):

Safety valve type: Safety valve approved atbar

Water temperature (°C) ⇒ inlet: ⇒ outlet:

SENKO

Vladimira Nazora 22, Štefanec, 40000 Čakovec, Hrvatska
Tel: +385 (0)40 33 73 44 • E-mail: info@senko.hr

www.senko.hr



*... THE SPIRIT OF TRADITION
IN MODERN FORMS FOR
A HEALTHY ENVIRONMENT.*

facebook

YouTube



You can find this Manual at <http://en.senko.hr/>

We reserve the right to change all pictures, technical details and colours of products, mentioned in this manual, without prior notice.